



Juliet Balcony Fitting Guide



01202 802111


www.crlonline.co

Step 1 – Choose your balcony

Firstly, measure your structural opening for your doors then add 300mm. for example if your doors are 900mm wide then the balcony required will be 1100mm x 1200mm.

Step 2 – Prep the fixings

Depending on what size balcony you have ordered you will need to drill 4-6 holes into your brickwork, please check the diagrams at the bottom of this guide for sizes. Once you have made your holes insert the M10 threaded rods with Masonry resin into the holes. (Both products will need to be purchased from your local Builders Merchant/ DIY Store). If installing into a wooden structure, then use a washer and nut to secure the threaded rod from the inside.



Step 3 – Fit the balcony

Now screw on half of the mounting brackets supplied by CRL ready for the glass to be lifted into position, once the glass has been lifted into position screw the other half of the bracket to secure the glass into place. Tighten with an Allen key